# WIFI RANGE EXTENDER
EAGLE 1500

Jensen®
OF SCANDINAVIA

INSTALLATION GUIDE
ENGLISH

---

1 Electrical Outlet

Connect Eagle 1500 to a power outlet within 3 metres from your wireless router.

2 Connect the Eagle 1500

Connect your PC/Mac to the Eagle 1500 using the enclosed network cable.

3 Internet browser

Open your browser (Chrome, Firefox or IE). If the Eagle 1500 page is not automatically displayed, enter the address http://jensen.setup and press ENTER.

Jensen®
OF SCANDINAVIA

| Wizard | System Status | Wireless | Tools |

Quick Setup

Range Extender Mode

Associated Root Channel

Security Mode   Auto select

Disable

Open Scan

Save   Cancel

Help
Quick Setup

Range Extender Mode:
This method requires you to set the wireless name of an associated root AP, Channel and Security.

4 Wireless Network

Choose your wireless network in the list.

Jensen®
OF SCANDINAVIA

| Wizard | System Status | Wireless | Tools |

Quick Setup

Range Extender Mode

Associated Root Channel   AirLink7000

Security Mode   10

WPA2-PSK

WPA Algorithms   ● AES   ○ TKIP   ○ TKIP&AES

Security Key   ● ● ● ● ● ● ●

Close Scan

Select	SSID	MAC Address	Channel	Security	Signal Strength
○	Magelle	34:21:09:18:81:18	6	WPA_AES	-75dBm
◉	AirLink7000	70:B1:4E:78:7E:11	6	WPA2_AES	-74dBm
○	Designhorse	60:33:4B:E0:17:C9	1	WPA_AES	-79dBm
○	AirLink7000	70:B1:4E:78:7E:11	6	WPA2_AES	-74dBm
○	Telenor4671	90:EF:68:16:F2:73	7	WPA2_AES	-71dBm

Help
Quick Setup

Range Extender Mode:
This method requires you to set the wireless name of an associated root AP, Channel and Security.

5 Password

Enter the password for the existing wireless network, and click SAVE. Wait while the device completes setup (approx. 2 min).

6 Completed

You may now disconnect the network cable and move Eagle 1500 to where you want to extend your range.

✱ Tip

Positioning of Eagle 1500
Move Eagle 1500 to where you want to extend your range.

Area of range:　■ EAGLE 1500　■ ROUTER

? FAQ

Unstable connection from Eagle 1500
Move Eagle 1500 closer to the wireless router and/or the channel the router is transmitting on, as interference may be the cause.

How do I reset Eagle 1500?
Press the RESET button next to the LAN port.

Does Eagle 1500 support 5GHz networks?
Eagle 1500 supports only 2.4GHz and is not capable of extending a 5GHz network.

📞 Support

Free 12 months of phone support!
Norway: 22 32 30 76
Sweden: 08 38 30 00
Denmark: 70 70 21 22
Finland: 09 455 21 22

Opening hours:
Monday-Friday: 08.00-20.00
Saturday : 14.00-18.00

You can also reach us by e-mail at
support@jensenscandinavia.com

Jensen®
OF SCANDINAVIA

www.jensenofscandinavia.com