


### Smart Plug




# Quick start guide version 1.0

Requires a neimgard hub



Insert the device (A) into the wall socket. The LED light (C) will flash red/blue for 5 seconds while booting up.




2.

1.

Open the **Heimgard app** and follow the steps listed here to connect to your device



## Press and hold the join button (B) for 3 seconds while your app is scanning for the device



Your device will appear in the Found Devices list. Click configure to add the device to a specific room

# How to use the device

You have three configuration options when setting up the device

Generic: You can view power consumption and control the device in any room

Example: Remotely turn on/off TV, electic fan, coffee machine, or other household appliance

Light: Connect a light into the Smart Plug and control that light individually or together with other lights in the room. Automate the lights with Schedules, Quick Rules, and Scenes Climate Control: Connect a heater or fan to the Smart Plug. If you have a smart temperature sensor you can control the climate conditions of the room. Automate the tempertaure with Schedules and Scenes

You can turn on and off the device by also clicking the Power Button (A)

#### LED description

Light On:	Power is On
Light Off:	Power is Off
Flashes Rapidly:	Waiting to pair
Flashes Slowly (x 6):	Device is reseting

#### Factory Reset

Press and hold the Reset Button (B) for 5 seconds to disconnect the device from the hub. The LED light will flash slowly (x 6) to indicate successful disconnect.

#### Need help?

Website: heimgard.com/support

Email: support@heimgard.com

Facebook: facebook.com/heimgardnorge/

Telephone: +47 649 44 422

Visit heimgard.com for more information and tips on how to use.

## Important safety

Read through these instructions and follow accordingly. 2. Clean only with dry soft cloth. Household cleaners and solvents can damage the finish on your device. З. Do not install near any heat sources such as radiators, heat registers, stoves or other device that produce heat. Do not use this device near water 4 5. Warning: To reduce the risk of fire or electric shock, do not expose this device to rain or moisture. Do not expose device to dripping or splashing. 6 7. Protect the attached cables from being walked on or pinched, particularly at plugs, convenience receptacles, and the point the exit the apparatus. Only use attachments/accessories specified by the manufacturer. 8. 9. Unplug this device during lightning storms or when unused for long periods of time. All servicing should be performed by gualified service personnel. 10. Servicing is required when the device has been damaged in any wav. Operating temperature: -10°C to +50°C 12. Operating relative humidity: < 95% RH (no condensation)

Dispose the product properly at the end of life. This is electronic waste which should be recycled accordingly.



